

CARTUCHOS

BIOTONER SISTEMAS
ECOLÓGICOS
C/ LAS NAVAS Nº 10 - 12
POLÍGONO INDUSTRIAL RIO DE JANEIRO
28110 ALGETE MADRID
CIF: B 82512765
TFNO: 902 112 055
comercial@biotoner.es



© ESTA TARIFA ESTA SUJETA A CAMBIOS LÓGICOS DE MERCADO

brother

BR-DR2005	Brother HL2035 Black Drum Unit VIRGIN
BR-DR2100	Brother HL2140/2150N/2170W Drum Unit VIRGIN
BR-DR2200	Brother HL2240/2250N/2270W Drum Unit VIRGIN
BR-DR3000	Brother HL5130/5140/5150D/5170DN Drum Unit VIRGIN
BR-DR3100	Brother HL5240/5250DN/5280DW Black Drum Toner VIRGIN
BR-DR3200	Brother HL5240/5350/5370 Black Drum Unit VIRGIN
BR-TN130/135BK	Brother HL4040CN Colour Empty Toner VIRGIN
BR-TN130/135C/M/Y	Brother HL4040CN Colour Empty Toner VIRGIN
BR-TN230B/C/M/Y	Brother HL3040/3070 Black & Colours Empty Toner VIRGIN
BR-TN245B/C/M/Y	Brother HL3140/3150/3170 B/C/M/Y Empty Toner VIRGIN
BR-TN320B/C/M/Y	Brother HL4150DN/4570CDW B/C/M/Y Empty Toner VIRGIN
BR-TN325B/C/M/Y	Brother HL4150DN/4570CDW B/C/M/Y Empty Toner VIRGIN
BR-TN2000	Brother HL2030/2040/2070 Black Empty Toner VIRGIN
BR-TN2005	Brother HL2035 Black Empty Toner VIRGIN
BR-TN2010	Brother HL2130/DCP7055/7065 Black Empty Toner VIRGIN
BR-TN2110	Brother HL2140/2150N/270W Black Empty Toner VIRGIN
BR-TN2120	Brother HL2140/2150N/270W HY Black Empty Toner VIRGIN
BR-TN2210	Brother HL2240/2250N/270W Black Empty Toner VIRGIN
BR-TN2220	Brother HL2240/2250N/270W HY Black Empty Toner VIRGIN
BR-TN3280	Brother HL5240/5340/5350/5370 HY Black Empty Toner VIRGIN
BR-TN3380	Brother HL5440/50/70/HL6180DW/MFC8950DW Black HC Empty Toner VIRGIN
BR-TN3130	Brother HL5240/5280DW Black Empty Toner VIRGIN
BR-TN3170	Brother HL5240/5250DN Black Empty Toner VIRGIN
BR-TN3230	Brother HL5240/5340/5350/5370 Black Empty Toner VIRGIN
BR-TN3280	Brother HL5240/5340/5350/5370 HY Black Empty Toner VIRGIN
BR-TN3330	Brother HL5440/50/70/HL6180DW/MFC8950DW Black Empty Toner VIRGIN
BR-TN6300/6600	Brother HL1250 Black Empty Toner VIRGIN

Canon

CA-E30	Canon FC310/330/530 Black Empty Toner VIRGIN
CA-FX10	Canon L100/120 Fax Black Empty Toner VIRGIN
CA-EP27	Canon LBP 3200/X25 Bk Empty Toner VIRGIN

DELL

DE-1720	Dell 1720/1720dn Black Empty Toner VIRGIN
DE-1815	Dell 1815 Black Empty Toner VIRGIN
DE-2330DN	Dell 2330D/DN Black Empty Toner VIRGIN
DE-2335DN	Dell 2335DN Black Empty Toner VIRGIN
DE-3110	Dell 3110 B/C/M/Y Empty Toner VIRGIN
DE-5210	Dell 5210 Black Empty Toner VIRGIN
DE-3130CN	Dell 3130cn B/C/M/Y Empty Toner Cartridge VIRGIN

CARTUCHOS



EP-S050166/67	Epson EPL-6200 Black Empty Toner VIRGIN
EP-S051111	EPL N3000 Black Empty Toner VIRGIN
EP-S051162/3/4/5	Epson Aculaser C2800 Y/M/C/B Empty Toner VIRGIN
EP-S050435/6/7/8	Epson Aculaser M2000 Series Black Empty Toner VIRGIN
EP-S051104	Epson Aculaser C1100 Drum Unit VIRGIN
EP-S051170/3	Epson M4000 Black Empty Toner VIRGIN



HP-C3909A/X	HP 5SI EPW-WX Black Empty Toner VIRGIN
HP-C4127X	HP Laserjet 4000 HY Black Empty Toner VIRGIN
HP-C4129X	HP Laserjet 5000 HY Black Empty Toner VIRGIN
HP-C4182X	HP Laserjet 8100 Black Empty Toner VIRGIN
HP-C8061A	HP Laserjet 4100 RY Black Empty Toner VIRGIN
HP-C8061x	HP Laserjet 4100 RY Black Empty Toner VIRGIN
HP-C8543X	HP Laserjet 9000 Black Empty Toner VIRGIN
HP-CB285A	HP Laserjet P1102/1102W Black Empty Toner Cartridge VIRGIN
HP-CB435A	HP Laserjet P1005/1006 Black Empty Toner VIRGIN
HP-CB436A	HP Laserjet P1505 Black Empty Toner VIRGIN
HP-CB540A	HP Laserjet CM1300/CP1210/CP1510 Black Empty Toner VIRGIN
HP-CB541/2/3A	HP Laserjet CM1300/CP1210/CP1510 Black Empty Toner VIRGIN
HP-CC364A	HP Laserjet P4014/4015/4515 Black Empty Toner VIRGIN
HP-CC364X	HP Laserjet P4015 Series Black HY Toner Cartridge VIRGIN
HP-CC530A	HP Laserjet CP2025/CM2320MFP Black Empty Toner VIRGIN
HP-CC531/2/3A	HP Laserjet CP2025/CM2320MFP Black Empty Toner VIRGIN
HP-CE255A	HP Laserjet P3015 Series Black Empty Toner Cartridge VIRGIN
HP-CE255X	HP Laserjet P3015 Series Black Empty Toner Cartridge VIRGIN
HP-CE260A	HP Laserjet CP4525/4025 Black Empty Toner VIRGIN
HP-CE261/2/3A	HP Laserjet CP4525/4025 Black Empty Toner VIRGIN
HP-CE260X	HP Laserjet CP4525/4025 Black Empty Toner VIRGIN
HP-CE264X	HP LaserJet CM4540 Black Empty Toner VIRGIN
HP-CE270A	HP LaserJet CP5520 Black Empty Toner VIRGIN
HP-CE271/2/3A	HP LaserJet CP5520 Black Empty Toner VIRGIN
HP-CE278A	HP Laserjet P1566/P1606DN Black Empty Toner VIRGIN
HP-CE285A	HP Laserjet P1102/1102W Black Empty Toner Cartridge VIRGIN
HP-CE310/1/2/3A	HP LaserJet CP1025 HP126 B/C/M/Y Empty Toner VIRGIN
HP-CE314A	HP 126A Color LaserJet Pro CP1020/1025 Imaging Drum
HP-CE320A	HP LaserJet CM1415/CP1525 HP128 Black Empty Toner VIRGIN
HP-CE321/2/3A	HP LaserJet CM1415/CP1525 HP128 Black Empty Toner VIRGIN
HP-CE390A/X	HP LaserJet M 4555 (90A) Black Empty Toner VIRGIN
HP-CE400A	HP 507A HY Black Empty Toner VIRGIN
HP-CE400X	HP 507A HY Black Empty Toner VIRGIN
HP-CE401/2/3A	HP 507A C/M/Y Empty Toner VIRGIN
HP-CE410A/X	HP Laser Pro 300 M351/375/NW400/451 Black Empty Toner VIRGIN
HP-CE411/2/3A	HP Laser Pro 300 M351/375/NW400/451 Black Empty Toner VIRGIN
HP-CE740A	HP LaserJet CP5225/5225N/5225D Black Empty Toner VIRGIN
HP-CE741/2/3A	HP LaserJet CP5225/5225N/5225D Black Empty Toner VIRGIN
HP-CE505A	HP 05A Laserjet P2035/P2055 SC Black Empty Toner VIRGIN
HP-CE505X	HP 05A Laserjet P2035/P2055 SC Black Empty Toner VIRGIN
HP-CF210A	HP 131A LaserJet Pro 200 M251/276 Black Toner VIRGIN
HP-CF280A	HP 80X LaserJet Pro M401/425 HC Toner VIRGIN
HP-CF280X	HP 80X LaserJet Pro M401/425 HC Toner VIRGIN
HP-Q1338A	HP Laserjet 4200 Black Empty Toner VIRGIN

CARTUCHOS

HP-Q1339A	HP Laserjet 4300 Black Empty Toner VIRGIN
HP-Q2670A	HP Laserjet 3500/3700 Black Empty Toner VIRGIN
HP-Q2671/2/3A	HP Laserjet 3500/3700 Black Empty Toner VIRGIN
HP-Q2681/2/3A	HP Laserjet 3700 C/Y/M Empty Toner VIRGIN
HP-Q5942A	HP Laserjet 4250/4350 RY Black Empty Toner America VIRGIN
HP-Q5942X	HP Laserjet 4250/4350 RY Black Empty Toner America VIRGIN
HP-Q5945A	HP Laserjet 4345 MFP Black Empty Toner VIRGIN
HP-Q5949A	HP Laserjet 1160/1320 RY Black Empty Toner VIRGIN
HP-Q5949X	HP Laserjet 1160/1320 RY Black Empty Toner VIRGIN
HP-Q5950A	HP Laserjet 4700 Black Empty Toner VIRGIN
HP-Q5951/2/3A	HP Laserjet 4700 Black Empty Toner VIRGIN
HP-Q6000A	HP Laserjet 2600n Black Empty Toner VIRGIN
HP-Q6001/2/3A	HP Laserjet 2600n Black Empty Toner VIRGIN
HP-Q6470A	HP Laserjet 3600/3800 Black Empty Toner VIRGIN
HP-Q6471/2/3A	HP Laserjet 3600/3800 Black Empty Toner VIRGIN
HP-Q6511A	HP Laserjet 2410/2420/2430 RY Black Empty Toner VIRGIN
HP-Q6511X	HP Laserjet 2410/2420/2430 RY Black Empty Toner VIRGIN
HP-Q7551A	HP Laserjet P3005 RY Black Empty Toner VIRGIN
HP-Q7516A	HP Laserjet 5200 Series Black Empty Toner VIRGIN
HP-Q7551X	HP Laserjet P3005 RY Black Empty Toner VIRGIN
HP-Q7553A	HP Laserjet P2015 RY Black Empty Toner VIRGIN
HP-Q7553X	HP Laserjet P2015 RY Black Empty Toner VIRGIN
HP-Q7560A	HP Laserjet 3000 Black Empty Toner VIRGIN
HP-Q7561/2/3A	HP Laserjet 3000 Black Empty Toner VIRGIN
HP-Q7570A	HP Laserjet M5025/M5035 Black Empty Toner VIRGIN
HP-Q7581/2/3A	HP Laserjet 3800 C/Y/M Empty Toner VIRGIN



LE-E360H11/21	Lex E360 Black Empty Toner VIRGIN
LE-MS310	Lex MS310 Black Empty Toner VIRGIN
LE-MS710	Lex MS710/812 Black Empty Toner VIRGIN
LE-12A6830/35	Lex Optra T520/522 Black Empty Toner VIRGIN
LE-E12016S	Lex E120 Black Empty Toner VIRGIN
LE-E260A11/21	Lex E260 Black Empty Toner VIRGIN
LE-E250A11/21	Lex E250/350/352/450 Black Empty Toner VIRGIN



OK-09004391/447	Okı B2500/2520/2540MFP Black Empty Toner Cartridge VIRGIN
OK-43866105/6/7/8	Okı C710 Y/M/C/B Empty Toner VIRGIN
OK-44574302	Okı B411/B431 Black Drum Unit VIRGIN
OK-B410OPC	Okı Type 11 B410/430/440 Drum Unit VIRGIN



SA-MLTD101L	Samsung ML2160/62/65/68W SCX4300/3405 HY Black Empty Toner VIRGIN
SA-MLTD101S	Samsung ML2160/62/65/68W SCX4300/3405 HY Black Empty Toner VIRGIN
SA-MLTD103L	Samsung ML2950/2955 SCX4728/4729 HY Black Empty Toner VIRGIN
SA-MLTD103S	Samsung ML2950/2955 SCX4728/4729 HY Black Empty Toner VIRGIN
SA-MLTD1042	Samsung ML1660/1665/SCX3200 Black Empty Toner VIRGIN
SA-MLTD1052L	Samsung MLT1910/1915/ML2580/SCX4600 Black Empty Toner VIRGIN
SA-MLTD205L	Samsung ML3310/ML3710 HY Black Empty Toner VIRGIN

CARTUCHOS

SA-MLTD205S	Samsung ML3310/ML3710 HY Black Empty Toner VIRGIN
SA-CLT406B/C/M/Y-CHIP	Samsung CLP360/65/68/CLX3300/05 With Chip B/C/M/Y Empty Toner VIRGIN
SA-CLT4072S-CHIP	Samsung CLP320/CLX3185 B/C/M/Y with Chip Empty Toner VIRGIN
SA-CLT4092B/C/M/Y	Samsung CLP310/315/CLX3170 With Chip B/C/M/Y Empty Toner VIR
SA-CLT4092B/C/M/Y-CHIP	Samsung CLP310/315/CLX3170 With Chip B/C/M/Y Empty Toner VIR

TINTA


Canon

CA-BC01	Canon BJ10E/10EX/10SX/20 Black Empty Inkjet VIRGIN
CA-BX2	Canon B220/310/360 Fax Black Empty Inkjet VIRGIN
CA-BX3	Canon B110/FaxB540 Black Empty Inkjet VIRGIN
CA-CL38	Canon CL-38 Pixma IP2500 Colour Empty Inkjet VIRGIN
CA-CL41	Canon CL-41 Pixma MP150 Colour Empty Inkjet VIRGIN
CA-CL51	Canon CL-51 Pixma MP150 Colour Empty Inkjet VIRGIN
CA-CL511	Canon MP480/260/240 Colour Empty Inkjet VIRGIN
CA-CL513	Canon Pixma MP480/260/240 Tricolour Empty Inkjet VIRGIN
CA-CL52	Canon CL-52 Pixma MP450 Photo Colour Empty Inkjet VIRGIN
CA-CL541	Canon Pixma MG2150/MG3150 C/M/Y Empty Inkjet VIRGIN
CA-PG37	Canon PG-37 Pixma IP2500 Black Empty Inkjet VIRGIN
CA-PG40	Canon PG-40 Pixma MP150 Black Empty Inkjet VIRGIN
CA-PG50	Canon PG-50 Pixma MP150 Black Empty Inkjet VIRGIN
CA-PG510	Canon MP480/260/240 Black Empty Inkjet VIRGIN
CA-PG540	Canon Pixma MG2150/MG3150 Black Empty Inkjet VIRGIN
CA-PG512	Canon Pixma MP480/260/240 Black Empty Inkjet VIRGIN



HP-51626A	HP Deskjet 500C Series Black Empty Inkjet VIRGIN
HP-51645A	HP Deskjet 1600C Black Empty Inkjet VIRGIN
HP-C1823D	HP Deskjet 710C Colour Empty Inkjet VIRGIN
HP-C6578A	HP Deskjet 970 HY Colour Empty Inkjet VIRGIN
HP-C6578D	HP Deskjet 970 HY Colour Empty Inkjet VIRGIN
HP-C6614D	HP Deskjet 610C/612C Black Empty Inkjet VIRGIN
HP-C6615D	HP 500/Deskjet 815C Black Empty Inkjet VIRGIN
HP-C6625A	HP Deskjet 840C Series Colour Empty Inkjet VIRGIN
HP-C6656A	HP Deskjet 5550 Series Black Empty Inkjet VIRGIN
HP-C6656G	HP Deskjet 5550 Series Black Empty Inkjet VIRGIN
HP-C6657A	HP Deskjet 5550 Series Colour Empty Inkjet VIRGIN
HP-C6657G	HP Deskjet 5550 Series Colour Empty Inkjet VIRGIN
HP-C8727A	HP Deskjet 3420 Black Empty Inkjet VIRGIN
HP-C8728A	HP Deskjet 3420 Colour Empty Inkjet VIRGIN
HP-C8765EE	HP 338 Black Empty Inkjet European Version VIRGIN
HP-C8766EE	HP 343 Black Empty Inkjet VIRGIN
HP-C9351AE	HP 21 Deskjet 3940 Black Empty Inkjet VIRGIN
HP-C9351CE	HP 21 Deskjet 3940 Black Empty Inkjet VIRGIN
HP-C9351GE	HP 21 Deskjet 3940 Black Empty Inkjet VIRGIN
HP-C9352AE	HP 22 Deskjet 3940 Colour Empty Inkjet VIRGIN
HP-C9352CE	HP 22 Deskjet 3940 Colour Empty Inkjet VIRGIN
HP-C9352GE	HP 22 Deskjet 3940 Colour Empty Inkjet VIRGIN
HP-C9361EE	HP 342 Deskjet 5440 Colour Empty Inkjet VIRGIN
HP-C9362EE	HP 336 Deskjet 5440 Black Empty Inkjet VIRGIN
HP-C9363EE	HP 344 HY Tricolour Empty Inkjet European Version VIRGIN

CARTUCHOS

HP-C9364EE	HP 337 Tricolour Empty Inkjet European Version VIRGIN
HP-CB334AE	HP 54 Black Empty Inkjet VIRGIN
HP-CB335EE	HP 350 Photosmart C5100 Black Empty Inkjet VIRGIN
HP-CB336EE	HP 350XL Photosmart C5100 Black Empty Inkjet VIRGIN
HP-CB337EE	HP 351 J5780/5785 Tricolour Empty Inkjet VIRGIN
HP-CB338EE	HP 351XL J5780/J5785 Tricolour Empty Inkjet VIRGIN
HP-CC640EE	HP 300 Deskjet D2560 Black Empty Inkjet Cartridge VIRGIN
HP-CC641EE	HP 300 Deskjet D2560 Black Empty Inkjet Cartridge VIRGIN
HP-CC643EE	HP 300 Deskjet D2560 Tricolour Empty Inkjet Cartridge VIRGIN
HP-CC644EE	HP 300 Deskjet D2560 Tricolour Empty Inkjet Cartridge VIRGIN
HP-CC653AE	HP 901 Officejet J4580 Black Empty Inkjet Cartridge VIRGIN
HP-CC654AE	HP 901XL Officejet J4580 Black Empty Inkjet Cartridge VIRGIN
HP-CC656AE	HP Deskjet 5550 Series Black Empty Inkjet VIRGIN
HP-CH561E	HP 301 D2050/D2050S/D1050 Black Empty Inkjet VIRGIN
HP-CH562E	HP 301 D2050/D2050S/D1050 Black Empty Inkjet VIRGIN
HP-CH563EE	HP 301 D2050/D2050S/D1050 Black Empty Inkjet VIRGIN
HP-CH564EE	HP 301 D2050/D2050S/D1050 Black Empty Inkjet VIRGIN
HP-SERIE 950/951	
	
LE-18C0035	Lex 35 Z815/P915/X5250 Tricolour Empty Inkjet VIRGIN
LE-18C0034	Lex 34 Z815/P915/X5250 Black Empty Inkjet VIRGIN

* SI NO LOCALIZA LAS REFERENCIAS DE LOS CONSUMIBLES QUE UTILIZA POR FAVOR, CONSULTENOS.